

# ICM 4.0

In-Line Contamination Monitor - WiFi technology integrated





# Contamination management

**INDEX**

|  | Page |
|--|------|
| ① HYDRAULIC FLUIDS                                 | 12   |
| ② FLUIDS CONTAMINATION                             | 12   |
| ③ EFFECTS OF CONTAMINATION ON HYDRAULIC COMPONENTS | 12   |
| ④ MEASURING THE SOLID CONTAMINATION LEVEL          | 13   |
| ⑤ RECOMMENDED CONTAMINATION CLASSES                | 16   |
| ⑥ WATER IN HYDRAULIC AND LUBRICATING FLUIDS        | 17   |

## 1 HYDRAULIC FLUIDS

The fluid is the vector that transmits power, energy within an oleodynamic circuit. In addition to transmitting energy through the circuit, it also performs additional functions such as lubrication, protection and cooling of the surfaces.

The classification of fluids used in hydraulic systems is coded in many regulatory references, different Standards.

The most popular classification criterion divides them into the following families:

- MINERAL OILS

Commonly used oil deriving fluids.

- FIRE RESISTANT FLUIDS

Fluids with intrinsic characteristics of incombustibility or high flash point.

- SYNTHETIC FLUIDS

Modified chemical products to obtain specific optimized features.

- ECOLOGICAL FLUIDS

Synthetic or vegetable origin fluids with high biodegradability characteristics.

The choice of fluid for an hydraulic system must take into account several parameters.

These parameters can adversely affect the performance of an hydraulic system, causing delay in the controls, pump cavitation, excessive absorption, excessive temperature rise, efficiency reduction, increased drainage, wear, jam/block or air intake in the plant.

The main properties that characterize hydraulic fluids and affect their choice are:

- DYNAMIC VISCOSITY

It identifies the fluid's resistance to sliding due to the impact of the particles forming it.

- KINEMATIC VISCOSITY

It is a widespread formal dimension in the hydraulic field.

It is calculated with the ratio between the dynamic viscosity and the fluid density.

Kinematic viscosity varies with temperature and pressure variations.

- VISCOSITY INDEX

This value expresses the ability of a fluid to maintain viscosity when the temperature changes.

A high viscosity index indicates the fluid's ability to limit viscosity variations by varying the temperature.

- FILTERABILITY INDEX

It is the value that indicates the ability of a fluid to cross the filter materials. A low filterability index could cause premature clogging of the filter material.

- WORKING TEMPERATURE

Working temperature affects the fundamental characteristics of the fluid. As already seen, some fluid characteristics, such as cinematic viscosity, vary with the temperature variation.

When choosing a hydraulic oil, must therefore be taken into account of the environmental conditions in which the machine will operate.

- COMPRESSIBILITY MODULE

Every fluid subjected to a pressure contracts, increasing its density.

The compressibility module identifies the increase in pressure required to cause a corresponding increase in density.

- HYDROLYTIC STABILITY

It is the characteristic that prevents galvanic pairs that can cause wear in the plant/system.

- ANTIOXIDANT STABILITY AND WEAR PROTECTION

These features translate into the capacity of a hydraulic oil to avoid corrosion of metal elements inside the system.

- HEAT TRANSFER CAPACITY

It is the characteristic that indicates the capacity of hydraulic oil to exchange heat with the surfaces and then cool them.

## 2 FLUID CONTAMINATION

Whatever the nature and properties of fluids, they are inevitably subject to contamination. Fluid contamination can have two origins:

- INITIAL CONTAMINATION

Caused by the introduction of contaminated fluid into the circuit, or by incorrect storage, transport or transfer operations.

- PROGRESSIVE CONTAMINATION

Caused by factors related to the operation of the system, such as metal surface wear, sealing wear, oxidation or degradation of the fluid, the introduction of contaminants during maintenance, corrosion due to chemical or electrochemical action between fluid and components, cavitation. The contamination of hydraulic systems can be of different nature:

- SOLID CONTAMINATION

For example rust, slag, metal particles, fibers, rubber particles, paint particles or additives

- LIQUID CONTAMINATION


For example, the presence of water due to condensation or external infiltration or acids

- GASEOUS CONTAMINATION

For example, the presence of air due to inadequate oil level in the tank, drainage in suction ducts, incorrect sizing of tubes or tanks.

## 3 EFFECTS OF CONTAMINATION ON HYDRAULIC COMPONENTS


Solid contamination is recognized as the main cause of malfunction, failure and early degradation in hydraulic systems. It is impossible to delete it completely, but it can be effectively controlled by appropriate devices.



Solid contamination mainly causes surface damage and component wear.

- **SURFACE EROSION**  
Cause of leakage through mechanical seals, reduction of system performance, variation in adjustment of control components, failures.
- **ADHESION OF MOVING PARTS**  
Cause of failure due to lack of lubrication.
- **DAMAGES DUE TO FATIGUE**  
Cause of breakdowns and components breakdown.

- **MODIFICATION OF FLUID PROPERTIES**  
(COMPRESSIBILITY MODULE, DENSITY, VISCOSITY)  
Cause of system's reduction of efficiency and of control.  
It is easy to understand how a system without proper contamination management is subject to higher costs than a system that is provided.
- **MAINTENANCE**  
Maintenance activities, spare parts, machine stop costs
- **ENERGY AND EFFICIENCY**  
Efficiency and performance reduction due to friction, drainage, cavitation.



Liquid contamination mainly results in decay of lubrication performance and protection of fluid surfaces.

## DISSOLVED WATER

- **INCREASING FLUID ACIDITY**  
Cause of surface corrosion and premature fluid oxidation
- **GALVANIC COUPLE AT HIGH TEMPERATURES**  
Cause of corrosion

## FREE WATER - ADDITIONAL EFFECTS

- **DECAY OF LUBRICANT PERFORMANCE**  
Cause of rust and sludge formation, metal corrosion and increased solid contamination
- **BATTERY COLONY CREATION**  
Cause of worsening in the filterability feature
- **ICE CREATION AT LOW TEMPERATURES**  
Cause damage to the surface
- **ADDITIVE DEPLETION**  
Free water retains polar additives

Gaseous contamination mainly results in decay of system performance.

- **CUSHION SUSPENSION**  
Cause of increased noise and cavitation.
- **FLUID OXIDATION**  
Cause of corrosion acceleration of metal parts.


## 4 MEASURING THE SOLID CONTAMINATION LEVEL

The level of contamination of a system identifies the amount of contaminant contained in a fluid.


This parameter refers to a unit volume of fluid.

The level of contamination may be different at different points in the system. From the information in the previous paragraphs it is also apparent that the level of contamination is heavily influenced by the working conditions of the system, by its working years and by the environmental conditions.


What is the size of the contaminating particles that we must handle in our hydraulic circuit?



HUMAN HAIR  
(75 µm)



MINIMUM DIMENSION  
VISIBLE WITH HUMAN EYES  
(40 µm)



TYPICAL CONTAMINANT  
DIMENSION IN A  
HYDRAULIC CIRCUIT  
(4-14 µm)


Contamination level analysis is significant only if performed with a uniform and repeatable method, conducted with standard test methods and suitably calibrated equipment.

To this end, ISO has issued a set of standards that allow tests to be conducted and express the measured values in the following ways.


- **GRAVIMETRIC LEVEL - ISO 4405**

The level of contamination is defined by checking the weight of particles collected by a laboratory membrane. The membrane must be cleaned, dried and desiccated, with fluid and conditions defined by the Standard.

The volume of fluid is filtered through the membrane by using a suitable suction system. The weight of the contaminant is determined by checking the weight of the membrane before and after the fluid filtration.



CLEAN  
MEMBRANE



CONTAMINATED  
MEMBRANE

# CONTAMINATION MANAGEMENT

## - CUMULATIVE DISTRIBUTION OF THE PARTICLES SIZE - ISO 4406

The level of contamination is defined by counting the number of particles of certain dimensions per unit of volume of fluid. Measurement is performed by Automatic Particle Counters (APC).

Following the count, the contamination classes are determined, corresponding to the number of particles detected in the unit of fluid.

The most common classification methods follow ISO 4406 and SAE AS 4059 (Aerospace Sector) regulations.

NAS 1638 is still used although obsolete.

### Classification example according to ISO 4406

The International Standards Organisation standard ISO 4406 is the preferred method of quoting the number of solid contaminant particles in a sample.

The code is constructed from the combination of three scale numbers selected from the following table.

The first number represents the number of particles that are larger than  $4 \mu\text{m}_{(c)}$ .

The second number represents the number of particles larger than  $6 \mu\text{m}_{(c)}$ .

The third scale number represents the number of particles in a millilitre sample of the fluid that are larger than  $14 \mu\text{m}_{(c)}$ .

ISO 4406 - Allocation of Scale Numbers

| Class | Number of particles per ml |           |
|-------|----------------------------|-----------|
|       | Over                       | Up to     |
| 28    | 1 300 000                  | 2 500 000 |
| 27    | 640 000                    | 1 300 000 |
| 26    | 320 000                    | 640 000   |
| 25    | 160 000                    | 320 000   |
| 24    | 80 000                     | 160 000   |
| 23    | 40 000                     | 80 000    |
| 22    | 20 000                     | 40 000    |
| 21    | 10 000                     | 20 000    |
| 20    | 5 000                      | 10 000    |
| 19    | 2 500                      | 5 000     |
| 18    | 1 300                      | 2 500     |
| 17    | 640                        | 1 300     |
| 16    | 320                        | 640       |
| 15    | 160                        | 320       |
| 14    | 80                         | 160       |
| 13    | 40                         | 80        |
| 12    | 20                         | 40        |
| 11    | 10                         | 20        |
| 10    | 5                          | 10        |
| 9     | 2.5                        | 5         |
| 8     | 1.3                        | 2.5       |
| 7     | 0.64                       | 1.3       |
| 6     | 0.32                       | 0.64      |
| 5     | 0.16                       | 0.32      |
| 4     | 0.08                       | 0.16      |
| 3     | 0.04                       | 0.08      |
| 2     | 0.02                       | 0.04      |
| 1     | 0.01                       | 0.02      |
| 0     | 0                          | 0.01      |

>  $4 \mu\text{m}_{(c)}$  = 350 particles

>  $6 \mu\text{m}_{(c)}$  = 100 particles


>  $14 \mu\text{m}_{(c)}$  = 25 particles

16 / 14 / 12

## ISO 4406 Cleanliness Code System

Microscope counting examines the particles differently to APCs and the code is given with two scale numbers only.

These are at  $5 \mu\text{m}$  and  $15 \mu\text{m}$  equivalent to the  $6 \mu\text{m}_{(c)}$  and  $14 \mu\text{m}_{(c)}$  of APCs.



- CUMULATIVE DISTRIBUTION OF THE PARTICLES SIZE - SAE AS 4059-1 and SAE AS 4059-2

Classification example according to

SAE AS4059 - Rev. E and SAE AS4059-2 - Rev. F

The code, prepared for the aerospace industry, is based on the size, quantity, and particle spacing in a 100 ml fluid sample. The contamination classes are defined by numeric codes, the size of the contaminant is identified by letters (A-F).

## SAE AS4059 - REV. E

It can be made a differential measurement (Table 1) or a cumulative measurement (Table 2)

Table 1 - Class for differential measurement

| Class | Dimension of contaminant<br>Maximum Contamination Limits per 100 ml |                           |                           |                           |                         |
|-------|---|---------------------------|---------------------------|---------------------------|-------------------------|
|       | 6-14 $\mu\text{m}_{(c)}$  | 14-21 $\mu\text{m}_{(c)}$ | 21-38 $\mu\text{m}_{(c)}$ | 38-70 $\mu\text{m}_{(c)}$ | >70 $\mu\text{m}_{(c)}$ |
| 00    | 125   | 22                        | 4                         | 1                         | 0                       |
| 0     | 250   | 44                        | 8                         | 2                         | 0                       |
| 1     | 500   | 89                        | 16                        | 3                         | 1                       |
| 2     | 1 000   | 178                       | 32                        | 6                         | 1                       |
| 3     | 2 000   | 356                       | 63                        | 11                        | 2                       |
| 4     | 4 000   | 712                       | 126                       | 22                        | 4                       |
| 5     | 8 000   | 1 425                     | 253                       | 45                        | 8                       |
| 6     | 16 000  | 2 850                     | 506                       | 90                        | 16                      |
| 7     | 32 000  | 5 700                     | 1 012                     | 180                       | 32                      |
| 8     | 64 000  | 11 400                    | 2 025                     | 360                       | 64                      |
| 9     | 128 000   | 22 800                    | 4 050                     | 720                       | 128                     |
| 10    | 256 000   | 45 600                    | 8 100                     | 1 440                     | 256                     |
| 11    | 512 000   | 91 200                    | 16 200                    | 2 880                     | 512                     |
| 12    | 1 024 000   | 182 400                   | 32 400                    | 5 760                     | 1 024                   |

|   |
|---|
| 6 - 14 $\mu\text{m}_{(c)}$ = 15 000 particles |
| 14 - 21 $\mu\text{m}_{(c)}$ = 2 200 particles |
| 21 - 38 $\mu\text{m}_{(c)}$ = 200 particles   |
| 38 - 70 $\mu\text{m}_{(c)}$ = 35 particles    |
| > 70 $\mu\text{m}_{(c)}$ = 3 particles        |
| SAE AS4059 REV E - Class 6                    |

Table 2 - Class for cumulative measurement

| Class | Dimension of contaminant<br>Maximum Contamination Limits per 100 ml |                        |                         |                         |                         |                         |
|-------|---|------------------------|-------------------------|-------------------------|-------------------------|-------------------------|
|       | >4 $\mu\text{m}_{(c)}$  | >6 $\mu\text{m}_{(c)}$ | >14 $\mu\text{m}_{(c)}$ | >21 $\mu\text{m}_{(c)}$ | >38 $\mu\text{m}_{(c)}$ | >70 $\mu\text{m}_{(c)}$ |
| 000   | 195   | 76                     | 14                      | 3                       | 1                       | 0                       |
| 00    | 390   | 152                    | 27                      | 5                       | 1                       | 0                       |
| 0     | 780   | 304                    | 54                      | 10                      | 2                       | 0                       |
| 1     | 1 560   | 609                    | 109                     | 20                      | 4                       | 1                       |
| 2     | 3 120   | 1 217                  | 217                     | 39                      | 7                       | 1                       |
| 3     | 6 250   | 2 432                  | 432                     | 76                      | 13                      | 2                       |
| 4     | 12 500  | 4 864                  | 864                     | 152                     | 26                      | 4                       |
| 5     | 25 000  | 9 731                  | 1 731                   | 306                     | 53                      | 8                       |
| 6     | 50 000  | 19 462                 | 3 462                   | 612                     | 106                     | 16                      |
| 7     | 100 000   | 38 924                 | 6 924                   | 1 224                   | 212                     | 32                      |
| 8     | 200 000   | 77 849                 | 13 849                  | 2 449                   | 424                     | 64                      |
| 9     | 400 000   | 155 698                | 27 698                  | 4 898                   | 848                     | 128                     |
| 10    | 800 000   | 311 396                | 55 396                  | 9 796                   | 1 696                   | 256                     |
| 11    | 1 600 000   | 622 792                | 110 792                 | 19 592                  | 3 392                   | 512                     |
| 12    | 3 200 000   | 1 245 584              | 221 584                 | 39 184                  | 6 784                   | 1 024                   |

|  |
|--|
| > 4 $\mu\text{m}_{(c)}$ = 45 000 particles |
| > 6 $\mu\text{m}_{(c)}$ = 15 000 particles |
| > 14 $\mu\text{m}_{(c)}$ = 1 500 particles |
| > 21 $\mu\text{m}_{(c)}$ = 250 particles   |
| > 38 $\mu\text{m}_{(c)}$ = 15 particles    |
| > 70 $\mu\text{m}_{(c)}$ = 3 particle      |
| SAE AS4059 REV E<br>6A/6B/5C/5D/4E/2F      |

The information reproduced on this page is a brief extract from SAE AS4059 Rev.E, revised in May 2005. For further details and explanations refer to the full Standard.

## SAE AS4059 - REV. F

It can be made a differential measurement (Table 1) or a cumulative measurement (Table 2)

Table 1 - Class for differential measurement

| Class | Dimension of contaminant<br>Maximum Contamination Limits per 100 ml |                           |                           |                           |                         | (3) |
|-------|---|---------------------------|---------------------------|---------------------------|-------------------------|-----|
|       | 5-15 $\mu\text{m}$  | 15-25 $\mu\text{m}$       | 25-50 $\mu\text{m}$       | 50-100 $\mu\text{m}$      | >100 $\mu\text{m}$      | (1) |
|       | 6-14 $\mu\text{m}_{(c)}$  | 14-21 $\mu\text{m}_{(c)}$ | 21-38 $\mu\text{m}_{(c)}$ | 38-70 $\mu\text{m}_{(c)}$ | >70 $\mu\text{m}_{(c)}$ | (2) |
| 00    | 125   | 22                        | 4                         | 1                         | 0                       |     |
| 0     | 250   | 44                        | 8                         | 2                         | 0                       |     |
| 1     | 500   | 89                        | 16                        | 3                         | 1                       |     |
| 2     | 1 000   | 178                       | 32                        | 6                         | 1                       |     |
| 3     | 2 000   | 356                       | 63                        | 11                        | 2                       |     |
| 4     | 4 000   | 712                       | 126                       | 22                        | 4                       |     |
| 5     | 8 000   | 1 425                     | 253                       | 45                        | 8                       |     |
| 6     | 16 000  | 2 850                     | 506                       | 90                        | 16                      |     |
| 7     | 32 000  | 5 700                     | 1 012                     | 180                       | 32                      |     |
| 8     | 64 000  | 11 400                    | 2 025                     | 360                       | 64                      |     |
| 9     | 128 000   | 22 800                    | 4 050                     | 720                       | 128                     |     |
| 10    | 256 000   | 45 600                    | 8 100                     | 1 440                     | 256                     |     |
| 11    | 512 000   | 91 200                    | 16 200                    | 2 880                     | 512                     |     |
| 12    | 1 024 000   | 182 400                   | 32 400                    | 5 760                     | 1 024                   |     |

|   |
|---|
| 6 - 14 $\mu\text{m}_{(c)}$ = 15 000 particles |
| 14 - 21 $\mu\text{m}_{(c)}$ = 2 200 particles |
| 21 - 38 $\mu\text{m}_{(c)}$ = 200 particles   |
| 38 - 70 $\mu\text{m}_{(c)}$ = 35 particles    |
| > 70 $\mu\text{m}_{(c)}$ = 3 particles        |
| SAE AS4059 REV F - Class 6                    |

- (1) Size range, microscope particle counts, based on longest dimension as measured per AS598 or ISO 4407.
- (2) Size range, APC calibrated per ISO 11171 or an optical or electron microscope with image analysis software, based on projected area equivalent diameter.
- (3) Contamination classes and particle count limits are identical to NAS 1638.

Table 2 - Class for cumulative measurement

| Class | Dimension of contaminant<br>Maximum Contamination Limits per 100 ml |                        |                         |                         |                         |                         | (1) |
|-------|---|------------------------|-------------------------|-------------------------|-------------------------|-------------------------|-----|
|       | >1 $\mu\text{m}$  | >5 $\mu\text{m}$       | >15 $\mu\text{m}$       | >25 $\mu\text{m}$       | >50 $\mu\text{m}$       | >100 $\mu\text{m}$      | (2) |
|       | >4 $\mu\text{m}_{(c)}$  | >6 $\mu\text{m}_{(c)}$ | >14 $\mu\text{m}_{(c)}$ | >21 $\mu\text{m}_{(c)}$ | >38 $\mu\text{m}_{(c)}$ | >70 $\mu\text{m}_{(c)}$ |     |
| 000   | 195   | 76                     | 14                      | 3                       | 1                       | 0                       |     |
| 00    | 390   | 152                    | 27                      | 5                       | 1                       | 0                       |     |
| 0     | 780   | 304                    | 54                      | 10                      | 2                       | 0                       |     |
| 1     | 1 560   | 609                    | 109                     | 20                      | 4                       | 1                       |     |
| 2     | 3 120   | 1 217                  | 217                     | 39                      | 7                       | 1                       |     |
| 3     | 6 250   | 2 432                  | 432                     | 76                      | 13                      | 2                       |     |
| 4     | 12 500  | 4 864                  | 864                     | 152                     | 26                      | 4                       |     |
| 5     | 25 000  | 9 731                  | 1 731                   | 306                     | 53                      | 8                       |     |
| 6     | 50 000  | 19 462                 | 3 462                   | 612                     | 106                     | 16                      |     |
| 7     | 100 000   | 38 924                 | 6 924                   | 1 224                   | 212                     | 32                      |     |
| 8     | 200 000   | 77 849                 | 13 849                  | 2 449                   | 424                     | 64                      |     |
| 9     | 400 000   | 155 698                | 27 698                  | 4 898                   | 848                     | 128                     |     |
| 10    | 800 000   | 311 396                | 55 396                  | 9 796                   | 1 696                   | 256                     |     |
| 11    | 1 600 000   | 622 792                | 110 792                 | 19 592                  | 3 392                   | 512                     |     |
| 12    | 3 200 000   | 1 245 584              | 221 584                 | 39 184                  | 6 784                   | 1 024                   |     |

|  |
|--|
| > 4 $\mu\text{m}_{(c)}$ = 45 000 particles   |
| > 6 $\mu\text{m}_{(c)}$ = 15 000 particles   |
| > 14 $\mu\text{m}_{(c)}$ = 1 500 particles   |
| > 21 $\mu\text{m}_{(c)}$ = 250 particles     |
| > 38 $\mu\text{m}_{(c)}$ = 15 particles      |
| > 70 $\mu\text{m}_{(c)}$ = 3 particle        |
| SAE AS4059 REV F<br>cpc* Class 6 6/6/5/5/4/2 |

\* cumulative particle count

- (1) Size range, optical microscope, based on longest dimension as measured per AS598 or ISO 4407.
- (2) Size range, APC calibrated per ISO 11171 or an optical or electron microscope with image analysis software, based on projected area equivalent diameter.



# CONTAMINATION MANAGEMENT

## - CLASSES OF CONTAMINATION ACCORDING TO NAS 1638 (January 1964)

The NAS system was originally developed in 1964 to define contamination classes for the contamination contained within aircraft components.

The application of this standard was extended to industrial hydraulic systems simply because nothing else existed at the time.

The coding system defines the maximum numbers permitted of 100 ml volume at various size intervals (differential counts) rather than using cumulative counts as in ISO 4406. Although there is no guidance given in the standard on how to quote the levels, most industrial users quote a single code which is the highest recorded in all sizes and this convention is used on MP Filtri APC's.

The contamination classes are defined by a number (from 00 to 12) which indicates the maximum number of particles per 100 ml, counted on a differential basis, in a given size bracket.

Size Range Classes (in microns)

| Maximum Contamination Limits per 100 ml |           |         |        |        |       |
|---|-----------|---------|--------|--------|-------|
| Class                                   | 5-15      | 15-25   | 25-50  | 50-100 | >100  |
| 00                                      | 125       | 22      | 4      | 1      | 0     |
| 0                                       | 250       | 44      | 8      | 2      | 0     |
| 1                                       | 500       | 89      | 16     | 3      | 1     |
| 2                                       | 1 000     | 178     | 32     | 6      | 1     |
| 3                                       | 2 000     | 356     | 63     | 11     | 2     |
| 4                                       | 4 000     | 712     | 126    | 22     | 4     |
| 5                                       | 8 000     | 1 425   | 253    | 45     | 8     |
| 6                                       | 16 000    | 2 850   | 506    | 90     | 16    |
| 7                                       | 32 000    | 5 700   | 1 012  | 180    | 32    |
| 8                                       | 64 000    | 11 400  | 2 025  | 360    | 64    |
| 9                                       | 128 000   | 22 800  | 4 050  | 720    | 128   |
| 10                                      | 256 000   | 45 600  | 8 100  | 1 440  | 256   |
| 11                                      | 512 000   | 91 200  | 16 200 | 2 880  | 512   |
| 12                                      | 1 024 000 | 182 400 | 32 400 | 5 760  | 1 024 |

|             |                    |
|-------------|--------------------|
| 5 - 15 µm   | = 42 000 particles |
| 15 - 25 µm  | = 2 200 particles  |
| 25 - 50 µm  | = 150 particles    |
| 50 - 100 µm | = 18 particles     |
| > 100 µm    | = 3 particles      |
| Class NAS 8 |                    |

## - CUMULATIVE DISTRIBUTION OF THE PARTICLES SIZE - ISO 4407

The level of contamination is defined by counting the number of particles collected by a laboratory membrane per unit of fluid volume. The measurement is done by a microscope. The membrane must be cleaned, dried and desiccated, with fluid and conditions defined by the Standard. The fluid volume is filtered through the membrane, using a suitable system.

The level of contamination is identified by dividing the membrane into a predefined number of areas and by counting the contaminant particles using a suitable laboratory microscope.

MICROSCOPE CONTROL AND MEASUREMENT



Example figure 1 and 2

ISO 4406  
SAE AS4059E Table 1  
NAS 1638  
SAE AS4059E Table 2

COMPARISON PHOTOGRAPHS  
1 graduation = 10µm



Fig. 1



Fig. 2

Class 16/14/11

Class 5

Class 6A/5B/5C

Class 22/20/17

Class 11

Class 12A/11B/11C

For other comparison photographs for contamination classes see the "Fluid Condition and Filtration Handbook".

## - CLEANLINESS CODE COMPARISON

Although ISO 4406 standard is being used extensively within the hydraulics industry other standards are occasionally required and a comparison may be requested. The table below gives a very general comparison but often no direct comparison is possible due to the different classes and sizes involved.

| ISO 4406   | SAE AS4059<br>Table 2  | SAE AS4059<br>Table 1                         | NAS 1638                                 |
|--|--|---|--|
| > 4 µm <sub>(c)</sub><br>6 µm <sub>(c)</sub><br>14 µm <sub>(c)</sub> | > 4 µm <sub>(c)</sub><br>6 µm <sub>(c)</sub><br>14 µm <sub>(c)</sub> | 4-6<br>6-14<br>14-21<br>21-38<br>38-70<br>>70 | 5-15<br>15-25<br>25-50<br>50-100<br>>100 |
| 23 / 21 / 18   | 13A / 12B / 12C  | 12  | 12                                       |
| 22 / 20 / 17   | 12A / 11B / 11C  | 11  | 11                                       |
| 21 / 19 / 16   | 11A / 10B / 10C  | 10  | 10                                       |
| 20 / 18 / 15   | 10A / 9B / 9B  | 9   | 9  |
| 19 / 17 / 14   | 9A / 8B / 8C   | 8   | 8  |
| 18 / 16 / 13   | 8A / 7B / 7C   | 7   | 7  |
| 17 / 15 / 12   | 7A / 6B / 6C   | 6   | 6  |
| 16 / 14 / 11   | 6A / 5B / 5C   | 5   | 5  |
| 15 / 13 / 10   | 5A / 4B / 4C   | 4   | 4  |
| 14 / 12 / 09   | 4A / 3B / 3C   | 3   | 3  |

## 5 RECOMMENDED CONTAMINATION CLASSES

The table below, gives a selection of maximum contamination levels that are typically issued by component manufacturer.

These relate to the use of the correct viscosity mineral fluid. An even cleaner level may be needed if the operation

is severe, such as high frequency fluctuations in loading, high temperature or high failure risk.

|  |                        |                        |                        |                       |                       |                       |
|--|------------------------|------------------------|------------------------|-----------------------|-----------------------|-----------------------|
| Piston pumps with fixed flow rate                | •                      |                        |                        |                       |                       |                       |
| Piston pumps with variable flow rate             |                        |                        | •                      |                       |                       |                       |
| Vane pumps with fixed flow rate                  |                        | •                      |                        |                       |                       |                       |
| Vane pumps with variable flow                    |                        |                        | •                      |                       |                       |                       |
| Engines  | •                      |                        |                        |                       |                       |                       |
| Hydraulic cylinders                              | •                      |                        |                        |                       |                       |                       |
| Actuators  |                        |                        |                        |                       | •                     |                       |
| Test benches                                     |                        |                        |                        |                       |                       | •                     |
| Check valve                                      | •                      |                        |                        |                       |                       |                       |
| Directional valves                               | •                      |                        |                        |                       |                       |                       |
| Flow regulating valves                           | •                      |                        |                        |                       |                       |                       |
| Proportional valves                              |                        |                        |                        | •                     |                       |                       |
| Servo-valves                                     |                        |                        |                        |                       | •                     |                       |
| Flat bearings                                    |                        |                        | •                      |                       |                       |                       |
| Ball bearings                                    |                        |                        |                        | •                     |                       |                       |
| ISO 4406 CODE                                    | 20/18/15               | 19/17/14               | 18/16/13               | 17/15/12              | 16/14/11              | 15/13/10              |
| Recommended filtration $\beta_{x(c)} \geq 1.000$ | $\beta_{20(c)} > 1000$ | $\beta_{15(c)} > 1000$ | $\beta_{10(c)} > 1000$ | $\beta_{7(c)} > 1000$ | $\beta_{7(c)} > 1000$ | $\beta_{5(c)} > 1000$ |




## 6 WATER IN HYDRAULIC AND LUBRICATING FLUIDS

### Water Content

In mineral oils and non aqueous resistant fluids water is undesirable. Mineral oil usually has a water content of 50-300 ppm (@40°C) which it can support without adverse consequences.

Once the water content exceeds about 300 ppm the oil starts to appear hazy. Above this level there is a danger of free water accumulating in the system in areas of low flow. This can lead to corrosion and accelerated wear.

Similarly, fire resistant fluids have a natural water which may be different to mineral oil.



### Saturation Levels

Since the effects of free (also emulsified) water is more harmful than those of dissolved water, water levels should remain well below the saturation point.

However, even water in solution can cause damage and therefore every reasonable effort should be made to keep saturation levels as low as possible. There is no such thing as too little water. As a guideline, we recommend maintaining saturation levels below 50% in all equipment.

### TYPICAL WATER SATURATION LEVEL FOR NEW OILS

Examples:

Hydraulic oil @ 30°C = 200 ppm = 100% saturation

Hydraulic oil @ 65°C = 500 ppm = 100% saturation



### W - Water and Temperature Sensing

“W” option, in MP Filtri Contamination Monitoring Products, indicates water content as a percentage of saturation and oil temperature in degrees centigrade. 100% RH corresponds to the point at which free water can exist in the fluid. i.e. the fluid is no longer able to hold the water in a dissolved solution.

The sensor can help provide early indication of costly failure due to free water, including but not exclusive to corrosion, metal surface fatigue e.g. bearing failure, reduced lubrication & load carrying characteristics.

Different oils have different saturation levels and therefore RH (relative humidity) % is the best and most practical measurement.

### Water absorber

Water is present everywhere, during storage, handling and servicing.

MP Filtri filter elements feature an absorbent media which protects hydraulic systems from both particulate and water contamination.

MP Filtri's filter element technology is available with inorganic microfiber media with a filtration rating 25 µm (therefore identified with media designation WA025, providing absolute filtration of solid particles to  $\beta_{x(c)} = 1000$ ).

Absorbent media is made by water absorbent fibres which increase in size during the absorption process. Free water is thus bonded to the filter media and completely removed from the system (it cannot even be squeezed out).



By removing water from your fluid power system, you can prevent such key problems as:

- corrosion (metal etching)
- loss of lubricant power
- accelerated abrasive wear in hydraulic components
- valve-locking
- bearing fatigue
- viscosity variance (reduction in lubricating properties)
- additive precipitation and oil oxidation
- increase in acidity level
- increased electrical conductivity (loss of dielectric strength)
- slow/weak response of control systems

Product availability - UFM Series:

UFM 041 - UFM 051 - UFM 091 - UFM 181 - UFM 919


## Description

### Automatic Particle Counters

#### In-Line Contamination Monitor - WiFi technology integrated

The ICM 4.0 automatically measures and displays particulate contamination, moisture and temperature levels in various hydraulic fluids.

It is designed specifically to be mounted directly to systems, where ongoing measurement or analysis is required, and where space and costs are limited.



### > Features & Benefits

- Integrated WiFi
- Mobile APP
- 8 channel contamination measurement & display
- Measures and displays the following international standard formats: ISO 4406:2017, NAS 1638, AS 4059E
- Moisture and temperature sensing fluid dependent
- Data logging and 4000 test result memory
- Manual, automatic and remote control flexibility
- Multicolour indicators via LCD (K versions) and LED with output alarm signals as standard
- Robust die cast aluminium construction
- LPA View software (included)
- Pressure max. 420 bar
- Environmental protection IP65/67 versatile
- Secondary connector to allow the simultaneous control/download of results during operation
- 4-20mA analogue output as standard

### Scope of Supply

- 1 x ICM 4.0 (Specific model will be as per ordered item)
- 1 x 3m Twisted Pair Cable Assembly
- 1 x Hard copy Quick start/wiring installation guide
- 1 x Hard copy Fluid Condition Handbook
- 1 x Digital copy of user guides/software/drivers
- 1 x Hard copy of calibration certificate

See Accessories at page 87.

### Status LED

All ICM 4.0 versions have a multicolour indicator on the front panel, which is used to indicate the status or alarm state. ICM-K versions also have a screen that changes colour. The alarm thresholds can be set from LPA-View via the serial interface.

### Screen and multicolor indicators

- Green indicates that the test result passed, i.e. none of the alarm thresholds were exceeded
- Yellow indicates that the lower cleanliness limit was exceeded, but not the upper one
- Red indicates that the upper cleanliness limit was exceeded
- Blue indicates that the upper water content limit was exceeded
- Red/Blue Alternating indicates both cleanliness and water content upper limits exceeded
- Violet indicates that the upper temperature limit was exceeded



Left facing view

Right facing view



Top view

Bottom view

## Technical data

### Technology

LED based Light Extinction Automatic Optical Particle Counter

### Particle Sizing

>4, 6, 14, 21, 25, 38, 50, 70  $\mu\text{m}_{(c)}$  to ISO 4406:2017 Standard

### Analysis range

ISO 4406:2017 Code 0 to 25

NAS 1638 Class 00 to 12

AS4059 Rev. E Table 1&2 Sizes A-F: 000

(Lower Limits are Test Time dependent)

### Accuracy

$\pm \frac{1}{2}$  code for 4,6,14  $\mu\text{m}_{(c)}$   $\pm 1$  code for larger sizes

### Calibration

Each unit individually calibrated with ISO Medium Test Dust (MTD)

based on ISO 11171, on equipment certified by I.F.T.S. ISO 11943

### Operating Flow Rate

20 - 400 ml/minute

### Viscosity range

$\leq 1000$  cSt

### Fluid temperature

From -25 °C to +80 °C

### Ambient Temperature

From -10 °C to +55 °C

### Temperature Measurement

$\pm 3$  °C

### Pressure

Minimum: 0.5 bar

Maximum: 420 bar

### Test time

Adjustable 10 - 3600 seconds. Factory set to 120 seconds.

Start delay & programmable test intervals available as standard

### Flow rate measurement

Indicator only

### Data Storage

Up to 4000 tests

### Communication options

RS485, MODBUS, CANBUS, 4-20mA time multiplex as standard

### Relays

Two solid state relays fitted to "R" version for output to alarm circuits

### Environmental Protection

IP 65/67 versatile IK04 Impact Protection

### Moisture Sensing

% RH  $\pm 3\%$

### Weight

1.6 kg

### Electrical Supply

Voltage 9-36V DC

### Power consumption

<2.2 W

### Outer Casing Finish

Polyurethane BS X34B. Colour BS381-638 (Dark Sea Grey)

Industry 4.0 ready with appropriate accessory product

### Wetted parts

M - C46400 Cu alloy, 316 stainless steel, FPM, FR4, sapphire.

N - 316 stainless steel, FPM, sapphire.

S - 316 stainless steel, perfluoro elastomer, sapphire, EPDM.

### Software

LPA View software (included)

## Wifi Connectivity


Wifi connectivity ensures you can access and share real-time data and analysis instantly via a number of different platforms.

- All connections from ICM 2.0:  
Modbus, Canbus, 4-20mA signal and Switched alarm relay outputs (WiFi replaces the need for the remote connector).  
Non-WiFi Connections also available.
- Cloud based systems:  
Capability to connect to customers own cloud-based systems via Modbus.  
User access to all ICMs on the same network, including remotely via VPN.
- Web browser readouts:  
Generated from the unique IP address of each ICM 4.0.
- Mobile App:  
Available for Apple iOS and Android devices.

## LPA View Software


The LPA View software is used with the LPA3, LPA2, CML2 and ICM particle counters. When connected to LPA View, MP Filtri CMPs can transfer results in realtime, or alternatively, historical results can be downloaded from the CMP's inbuilt memory.

- Runs on Windows XP, 7, and Windows 10
- Full adjustment & control of product settings, test times and alarms
- Easy test report generation
- Trend analysis
- Graphical display options
- Universal format across our contamination monitoring product range




## Hydraulic Circuit


TYPICAL PRESSURE LINE




TYPICAL RETURN LINE



For installation guidance please visit:  
[www.mpfiltri.com/products/contamination-monitoring-products/icm-40-118.html#cont](http://www.mpfiltri.com/products/contamination-monitoring-products/icm-40-118.html#cont)



## Dimensions



It is important to ensure a minimum 0.5 bar differential across the ICM4.0

The ICM 4.0 can be used as a standalone product or can be controlled by external PC, PLC.

## Designation & Ordering code

| AUTOMATIC PARTICLE COUNTER ICM 4.0   |  |  |  |  |                        |  |     |   |   |   |   |    |     |
|--|--|--|--|--|------------------------|--|-----|---|---|---|---|----|-----|
| Series   |  |  |  |  | Configuration example: |  | ICM | W | M | K | R | G1 | 4.0 |
| ICM In-Line Contamination Monitor  |  |  |  |  |                        |  |     |   |   |   |   |    |     |
| Moisture Sensor (RH%)  |  |  |  |  |                        |  |     |   |   |   |   |    |     |
| 0 Without moisture and temperature sensor  |  |  |  |  |                        |  |     |   |   |   |   |    |     |
| W With moisture and temperature sensor   |  |  |  |  |                        |  |     |   |   |   |   |    |     |
| Fluid compatibility  |  |  |  |  |                        |  |     |   |   |   |   |    |     |
| M Mineral/synthetic oils   |  |  |  |  |                        |  |     |   |   |   |   |    |     |
| N Subsea and water based fluids (*)  |  |  |  |  |                        |  |     |   |   |   |   |    |     |
| S M & N type fluids & phosphate esters/aviation fluids (*) - G3 port option only |  |  |  |  |                        |  |     |   |   |   |   |    |     |
| Keypad / Display   |  |  |  |  |                        |  |     |   |   |   |   |    |     |
| 0 Without LCD and keypad control   |  |  |  |  |                        |  |     |   |   |   |   |    |     |
| K With LCD and keypad control  |  |  |  |  |                        |  |     |   |   |   |   |    |     |
| Device output  |  |  |  |  |                        |  |     |   |   |   |   |    |     |
| R With relays / external alarm outputs   |  |  |  |  |                        |  |     |   |   |   |   |    |     |
| Connections  |  |  |  |  |                        |  |     |   |   |   |   |    |     |
| G1 M16 x 2 test points   |  |  |  |  |                        |  |     |   |   |   |   |    |     |
| G3 1/4"BSPP female ports   |  |  |  |  |                        |  |     |   |   |   |   |    |     |
| G4 7/16th UNF female ports   |  |  |  |  |                        |  |     |   |   |   |   |    |     |
| Series   |  |  |  |  |                        |  |     |   |   |   |   |    |     |
| 4.0 ICM 4.0 with integral WiFi   |  |  |  |  |                        |  |     |   |   |   |   |    |     |

(\*) **N** and **S** version, moisture sensor (**W**) not available